


LS2208 barcode scanner




Set All Defaults

To work with OPOS driver:

1. Run Symbol OPOS Driver v3.31.0001.exe
2. Scan two barcodes below.



OPOS/JPOS



IBM Hand-Held USB

To scan interleaved 2of5 barcode any length, scan the barcode below.



I 2 of 5 - Any Length

To add Enter suffix scan three barcodes below.



Scan Options



<DATA> <SUFFIX>



Enter

To add Down arrow suffix scan three barcodes below.



Scan Options



<DATA> <SUFFIX>



Send **Down Arrow** Key